








Windows 10	 5.14.0.14916 USB / RS-232 For Surface Capacitive / Resistive / Surface Acoustic Wave / infrared.	2016/04/14
	 5.14.0.14916 USB / RS-232 For Projected Capacitive. The driver is a mouse emulation driver. If your USB interface touch device is projected capacitive type and Windows version is Windows 10 or later, we suggest you do not install this driver. There is a HID touch digitizer build-in driver in Windows 10.	2016/04/14
Windows 8.1 Windows 8 Windows Embedded 8 Embedded 8.1 Industry Embedded 8.1 Pro Embedded 8 Standard Windows 7 Windows Embedded 7 Embedded Enterprise 7 Embedded Standard 7 Embedded POSReady 7 Windows XP Windows Embedded POSReady 2009 Windows 2000	 5.13.0.14917 USB / RS-232 For Surface Capacitive / Resistive / Surface Acoustic Wave / infrared.	2016/04/14
	 5.13.0.14917 USB / RS-232 For Projected Capacitive. The driver is a mouse emulation driver. If your USB interface touch device is projected capacitive type and Windows version is Windows 7 or later, we suggest you do not install this driver. There is a HID touch digitizer build-in driver in Windows 7 and 8.	2016/04/14
Windows 2000 Windows XP Windows Vista	 5.12.0.12204 PS2	2014/06/19
Windows XP Embedded	 5.13.0.12628	2014/05/20
	 5.13.0.12706 For Projected Capacitive	2014/05/20